

Bluelab Nutrient Monitor™ Troubleshooting

Problem	Possible Reason	Possible Solution
No display reading	Batteries dead.	Replace batteries by following the steps on page 2 of the Nutrient Monitor Manual. Rechargeable batteries are never used.
	Batteries inserted incorrectly.	Check battery direction.
	Screen damaged.	Return for repair, or replace unit.
Nutrient readings Inaccurate	Probe contaminated.	To clean the probe, follow the steps on page 4 of the Nutrient Monitor Manual. If using oily additives the probe will need to be cleaned more frequently and thoroughly.